

Novacron amplifier quick setup and operation instructions

Installation: Emplace the amps in your system. Connect the preamp cable to the appropriate input connector on the rear of the amp. If you use the RCA input connector, make sure the shorting plug is installed between pins 1 & 3 on the XLR connector else a buzz will result. Verify that the power switch is OFF and connect AC power to the AC input connector on the rear of the amp. Connect the negative speaker cable to the negative output terminal and the positive speaker cable to the positive connection, which is towards the front in either channel.

Setup: Install the tubes in their sockets. The smaller sockets take the 6SN7 driver tubes. If using NOS types, the front tubes should have a -GTA or -GTB suffix. All other sockets take the 6C33 output tube Engage the STANDBY (middle switch position) and verify that the tubes are lit. Allow for 5 minutes for the power tubes to warm up. Meanwhile, turn all 4 bias controls fully counterclockwise. Engage the ON position (upmost) of the switch. Place the meter switch by the speaker terminals in the down position and the meter will read. The amplifier is now fully powered up and ready for the bias procedure.

Bias adjustment: Start by adjusting one of the front bias controls so that a reading of 200 ma is obtained on the meter (if the meter goes backwards, set the adjacent control instead). Adjust the associated (rear) control so the reading goes back to zero. Repeat for the other set of controls. To test the settings the controls must be set back to fully counterclockwise and the procedure repeated. After 30 minutes, reset the bias to 200 ma per tube. This should be checked again at one hour. If the meter fails to respond to a control, check the rear panel 1.5 Amp fuses and/or the associated output tube. A blown fuse indicates a bad tube associated with the control. NOTE: It is impossible to set the bias without knowing the condition of the tubes.

Operation: Place the meter switch in the up position. The amplifier is now completely operational. The amplifier is designed for continuous operation, but if you are not currently listening, place the amp in standby to increase output tube life and save energy.

Tube Condition: The bias procedure tells you the condition of the tubes. If a tube cannot be set to the correct value after 30 minutes of operation, it or its associated driver is weak. Uncontrollable readings on the meter indicate a short in a tube. Arc-over in an output tube (indicated by a popping sound at the time of failure) may blow a rear panel protection fuse. The tube will be unreliable if this occurs replacement is indicated.

LIMITED WARRANTY ON ATMASPHERE MUSIC SYSTEMS PRODUCTS

This warranty on your ATMA-SPHERE MUSIC SYSTEMS product, which is distributed and warranted by ATMA-SPHERE MUSIC SYSTEMS, shall remain in effect for two (2) years from the date of consumer purchase, provided the enclosed registration form is completed and returned to ATMASPHERE MUSIC SYSTEMS within ten days of purchase.

WHAT IS COVERED:

Except as specified below, this warranty covers all defects in materials and workmanship. The following are NOT covered by the two year limited warranty:

Tubes are covered for 90 days, with the following exclusions, as per the rest of the warranty:

Damage occurring during shipment (present claims to carrier).

Damage resulting from failure or inability to follow proper instructions.

Damage resulting from the performance of repairs or modifications by other than ATMA-SPHERE MUSIC SYSTEMS.

WHAT WE WILL PAY FOR:

ATMA-SPHERE MUSIC SYSTEMS will pay for all labor and material expenses for repairs covered by this warranty.

HOW TO OBTAIN WARRANTY SERVICE:

If your unit requires repairs covered by this warranty, you MUST obtain a return authorization number from ATMA-SPHERE MUSIC SYSTEMS. You are responsible for transporting the unit to ATMA-SPHERE MUSIC SYSTEMS, 160 So. Wheeler St., St. Paul, Minn. 55105. You must pay the initial shipping charges, but ATMA-SPHERE MUSIC SYSTEMS will pay the return charges, if the repairs are covered by the warranty. All products MUST be shipped in the original carton(s) or in replacement cartons supplied by ATMA-SPHERE MUSIC SYSTEMS. Contact ATMA-SPHERE MUSIC SYSTEMS for replacement cartons and cost.

LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT, AT OUR OPTION, OF ANY DEFECTIVE PRODUCT AND SHALL IN NO EVENT INCLUDE INCIDENTAL OR CONSEQUENTIAL DAMAGE OF ANY KIND.

This warranty is not transferable. Implied warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty. This warranty sets forth all expressed warranties made with regard to the above referenced product. We neither assume nor authorize any other liability in connection with the sale or any shipment of products. This warranty gives you specific legal rights and you may also have other rights which vary from state

to state. We reserve the right to make changes and improvements in our products without incurring any obligation to similarly alter products previously purchased.

WARRANTY REGISTRATION FORM

IMPORTANT: This form must be filled out and returned to ATMA-SPHERE MUSIC SYSTEMS within 10 days of purchase to validate the warranty! Please type or print clearly.

NAME				
Address				
City or town		State	zipcode	
Country				
Name of dealership_				
Model	Date of purchase	serial #	price	
Optional section for o	ur records and information:			
Comments concerning	g your dealer			
Comments concerning product	g this			
list the components in system_	n your			
comments, suggestio	ns			